



# **Play-Fi Device (**

**Unison**


**MartinLogan**

**7CB77B02932D**




**Fri September 9 2022**

### Front Left



● Target Curve ● Measurement Curve ● Corrected Curve

### Front Right



● Target Curve ● Measurement Curve ● Corrected Curve

## **Speaker Profile Settings**

Profile1 uses Measurement A

## **List of Speakers Enabled**

### **Profile1:**

· Fronts

## **Level Settings**

### **Profile1:**

System-Wide Level Target: 0 dB

Front Left: 0 dB

Front Right: 0 dB

## **Target Settings**

### **Profile1:**

Room Gain: 6 dB

Room Gain Center Frequency: 200 Hz

Deep Bass Boost: 0 dB

Deep Bass Boost Center Frequency: 50 Hz

Tilt Level: 0 dB

Tilt Start Frequency: 100 Hz

### **FRONTS**

Subwoofer Crossover Frequency (or Low-Frequency Extension): 24 Hz

Send Bass to Sub (or Low-Frequency Extension Slope): 2nd

High-Frequency Roll Off: 1.29

Maximum Correction Frequency: 2000 Hz